# Aspire 5542/5242 Series

**Quick Guide** 

Aspire 5542/5242 Series Quick Guide Original Issue: 08/2009		
Aspire 5542/5242 Series Notebook PC		
Model number:		
Serial number:		
Date of purchase:		
Place of purchase:		

Copyright © 2009. All Rights Reserved.

## First things first

We would like to thank you for making an Acer notebook your choice for meeting your mobile computing needs.

#### Your guides

To help you use your Acer notebook, we have designed a set of guides:

First off, the Just for Starters... poster helps you get started with setting up your computer.

The Aspire Series Generic User Guide contains useful information applying to all models in the Aspire product series. It covers basic topics such as Acer's Empowering Technology, using the keyboard, audio, etc. Please understand that due to its nature, the **Generic User Guide** as well as the **AcerSystem User Guide** mentioned below will occasionally refer to functions or features which are only contained in certain models of the series, but not necessarily in the model you purchased. Such instances are marked in the text with language such as "only for certain models".

The **Quick Guide** introduces you to the basic features and functions of your new computer. For more on how your computer can help you to be more productive, please refer to the AcerSystem User Guide. This guide contains detailed information on such subjects as system utilities, data recovery, expansion options and troubleshooting. In addition it contains warranty information and the general regulations and safety notices for your notebook. It is available in Portable Document Format (PDF) and comes preloaded on your notebook. Follow these steps to access it:

1 Click on Start, All Programs, AcerSystem.

2 Click on AcerSystem User Guide.



Note: Viewing the file requires Adobe Reader. If Adobe Reader is not installed on your computer, clicking on AcerSystem User Guide will run the Adobe Reader setup program first. Follow the instructions on the screen to complete the installation. For instructions on how to use Adobe Reader, access the Help and Support menu.

## Your Acer notebook tour

After setting up your computer as illustrated in the **Just for Starters...** poster, let us show you around your new Acer notebook.

#### Top view



#	lcon	Item	Description
1		Acer Crystal Eye webcam	Web camera for video communication.
2		Display screen	Also called Liquid-Crystal Display (LCD), displays computer output (Configuration may vary by models).
3	Ф	Power button	Turns the computer on and off.

#	lcon	Item	Description
4	Ö	Wireless LAN communication button/indicator	Enables/disables the wireless LAN function. Indicates the status of wireless LAN communication.
	*	Bluetooth communication button/indicator	Enables/disables the Bluetooth function. Indicates the status of Bluetooth communication. (only for certain models)
		Backup key	Launches Acer Backup Management for three-step data backup.
5	<b>*</b>	HDD	Indicates when the hard disk drive is active.
	1	Num Lock	Lights up when Num Lock is activated.
	A	Caps Lock	Lights up when Caps Lock is activated.
6		Keyboard	For entering data into your computer.
7		Touchpad	Touch-sensitive pointing device which functions like a computer mouse.
8		Click buttons (left, center* and right)	The left and right buttons function like the left and right mouse buttons. *The center button serves as Acer Bio-Protection fingerprint reader supporting Acer FingerNav 4-way control function (only for certain models).
9	<b>*</b>	Power <sup>1</sup>	Indicates the computer's power status.
	₫	Battery <sup>1</sup>	Indicates the computer's battery status.  1. Charging: The light shows amber when the battery is charging.  2. Fully charged: The light shows blue when in AC mode.
10		Palmrest	Comfortable support area for your hands when you use the computer.
11	7	Touchpad toggle	Turns the internal touchpad on and off.
12	100	Microphone	Internal microphone for sound recording.
13	+/-	Volume Up/ Volume Down	Increase system volume/decrease system volume.
14	Р	Programmable key	User-programmable.

#	lcon	Item	Description
15		Speakers	Left and right speakers deliver stereo audio output.

1. The front panel indicators are visible even when the computer cover is closed up.


#### Hotkeys

The computer employs hotkeys or key combinations to access most of the computer's controls like screen brightness, volume output.

To activate hotkeys, press and hold the **<Fn>** key before pressing the other key in the hotkey combination.

Hotkey	lcon	Function	Description
<fn> + <f2></f2></fn>	<b>&amp;</b>	System property	Starts System Property for displaying system information.
<fn> + <f3></f3></fn>	*	Bluetooth	Enables/disables the Bluetooth function.
<fn> + <f4></f4></fn>	Z <sup>z</sup>	Sleep	Puts the computer in Sleep mode.
<fn> + <f5></f5></fn>		Display toggle	Switches display output between the display screen, external monitor (if connected) and both.
<fn> + <f6></f6></fn>	*	Screen blank	Turns the display screen backlight off to save power. Press any key to return.
<fn> + <f8></f8></fn>	<b>₫/₫</b> »	Speaker toggle	Turns the speakers on and off.
<fn> + &lt;▷&gt;</fn>	Ö	Brightness up	Increases the screen brightness.
<fn> + &lt; &lt;&gt;&gt;</fn>		Brightness down	Decreases the screen brightness.
<fn> + &lt;△&gt;</fn>	(1)	Volume up	Increases the sound volume.
<fn> + &lt;▽&gt;</fn>	<b>(</b> )	Volume down	Decreases the sound volume.

#### Closed front view



#	lcon	Item	Description
1	PRO	Multi-in-1 card reader	Accepts Secure Digital (SD), MultiMediaCard (MMC), Memory Stick (MS), Memory Stick PRO (MS PRO), xD-Picture Card (xD).  Note: Push to remove/install the card. Only one card can operate at any given time.
2		Latch	Locks and releases the lid.

## Rear view



#	Item	Description
1	Ventilation slots	Enable the computer to stay cool, even after prolonged use.

## Left view



#	lcon	Item	Description
1	==	DC-in jack	Connects to an AC adapter.
2	뫎	Ethernet (RJ-45) port	Connects to an Ethernet 10/100/1000- based network.
3	HDMI	HDMI port	Supports high definition digital video connections.
4		External display (VGA) port	Connects to a display device (e.g., external monitor, LCD projector).
5	<b>◆</b>	USB 2.0 port	Connect to USB 2.0 devices (e.g., USB mouse, USB camera).
6	( <del>+))</del>	Line-in jack	Accepts audio line-in devices (e.g., audio CD player, stereo walkman, mp3 player)
	100	Microphone-in jack	Accepts inputs from external microphones.
	SPDIF	Headphones/speaker/ line-out jack with S/PDIF support	Connects to audio line-out devices (e.g., speakers, headphones).

## Right view



#	lcon	Item	Description
1	<b>●</b> ✓•+	USB 2.0 port	Connects to USB 2.0 devices (e.g., USB mouse, USB camera).
2		Optical drive	Internal optical drive; accepts CDs or DVDs.
3		Optical disk access indicator	Lights up when the optical drive is active.
4		Optical drive eject button	Ejects the optical disk from the drive.
5		Emergency eject hole	Ejects the optical drive tray when the computer is turned off.  Note: Insert a paper clip to the emergency eject hole to eject the optical drive tray when the computer is off.
6		Modem (RJ-11) port	Connects to a phone line.
7	ĸ	Kensington lock slot	Connects to a Kensington-compatible computer security lock.

## Base view



#	Icon	Item	Description
1	<u>+</u>	Battery bay	Houses the computer's battery pack.
2		Battery release latch	Releases the battery for removal.
3		Battery lock	Locks the battery in position.
4		Hard disk bay	Houses the computer's hard disk (secured with screws).
5		Memory compartment	Houses the computer's main memory.
6		Ventilation slots and cooling fan	Enable the computer to stay cool, even after prolonged use. <b>Note</b> : Do not cover or obstruct the opening of the fan.

## **Specifications**

•		
Operating	•	Genuine Windows 7 <sup>®</sup>
system		
Platform	•	AMD Turion <sup>™</sup> II Ultra dual-core processor*
	•	AMD Turion <sup>™</sup> II dual-core processor*
	•	AMD Athlon <sup>™</sup> 64 II dual-core processor*
	•	Mobile AMD Sempron <sup>™</sup> processor*
	•	AMD M880G Chipset
	•	Acer InviLink <sup>™</sup> Nplify <sup>™</sup> 802.11b/g/Draft-N*
	•	Acer InviLink <sup>™</sup> 802.11b/g*
System memory	•	Dual-Channel SDRAM support
	•	Up to 2 GB of DDR2 667 MHz memory, upgradeable
-		to 4 GB using two soDIMM modules
Display	•	16:9 aspect ratio
Coopline	•	15.6" HD 1366 x 768
Graphics	•	ATI Radeon <sup>™</sup> HD 4200 Graphics*
	•	ATI Mobility Radeon <sup>™</sup> HD 4570*
Audio	•	Dolby <sup>®</sup> -optimized surround sound system with two
		built-in stereo speakers
	•	True5.1-channel surround sound output High-definition audio support
	:	S/PDIF (Sony/Philips Digital Interface) support for
		digital speakers
	•	MS-Sound compatible
	•	Built-in microphone
Storage	•	2.5" hard disk drive
subsystem	•	Optical drive options:
		<ul> <li>Blu-ray Disc<sup>™</sup>/DVD-Super Multi double-layer drive*</li> </ul>
		<ul> <li>DVD-Super Multi double-layer drive*</li> </ul>
	•	Multi-in-1 card reader
Communication	•	Integrated Acer Crystal Eye webcam* WLAN:
		<ul> <li>Acer InviLink<sup>™</sup> Nplify<sup>™</sup> 802.11b/g/Draft-N*</li> </ul>
		<ul> <li>Acer InviLink<sup>™</sup> 802.11b/g*</li> </ul>
	•	WPAN: Bluetooth® 2.1+Enhanced Data Rate (EDR)*
	•	LAN: Gigabit Ethernet; Wake-on-LAN ready
	•	Modem: 56K ITU V.92; Wake-on-Ring ready
Privacy control	•	Acer Bio-Protection fingerprint solution*
	•	BIOS user, supervisor, HDD passwords
	•	Kensington lock slot

Dimensions	• 383 (W) x 250 (D) x 26/37 (H) mm
and weight	(15.1 x 9.9 x 1.03/1.5 inches)
	<ul> <li>2.8 kg (6.16 lbs.) with 6-cell battery pack</li> </ul>
Power	• ACPI 3.0
subsystem	<ul> <li>48.8 W 4400 mAh</li> </ul>
	• 3-pin 65 W AC adapter*
	• 3-pin 90 W AC adapter*
	ENERGY STAR®*
Special keys	• 103-/104-/107-key keyboard
and controls	<ul> <li>Touchpad pointing device</li> </ul>
I/O interface	Acer Bio-Protection fingerprint reader*
	<ul> <li>Multi-in-1 card reader (SD/MMC/MS/MS PRO/xD)</li> </ul>
	USB 2.0 port
	<ul> <li>HDMI<sup>™</sup> port with HDCP support</li> </ul>
	<ul> <li>External display (VGA) port</li> </ul>
	<ul> <li>Headphones/speaker/line-out jack with S/PDIF</li> </ul>
	support
	Microphone-in jack
	• Line-in jack
	• Ethernet (RJ-45) port
	<ul> <li>Modem (RJ-11) port</li> </ul>
	DC-in jack for AC adapter
Environment	Temperature:
	<ul> <li>Operating: 5 °C to 35 °C</li> </ul>
	<ul> <li>Non-operating: -20 °C to 65 °C</li> </ul>
	Humidity (non-condensing):
	<ul> <li>Operating: 20% to 80%</li> </ul>
	Non-operating: 20% to 80%



Note: \* Only for certain models



**Note:** The specifications listed above are for reference only. The exact configuration of your PC depends on the model purchased.